


Instructions Manual

Beauty instrument

WKB013

HIGH FREQUENCY



WK
Imported by
WEEKO BARCELONA SL

Pol. Ind. La Vall d'an
Camí de Garreta, 92
08600 Berga
Barcelona - Spain
T. +34 93 824 90 20
E. info@weelko.com

VERSION 1.0

Thank you sincerely for choosing our product. This manual is compiled to help users operate this instrument effectively. We hope our company's products and services will bring you a distinguished experience.

This user manual contains all general information about the instrument. It serves as the starting point for new users to begin using the instrument, as it provides a general introduction to the system, explains how it works, and details the instrument's installation and various operation methods.

Usage Precautions

1. Before turning on the machine, be sure to read the user manual carefully. Operators must be familiar with the user manual and operation methods, and the instrument must be managed by a designated person;
2. Do not use a power strip to avoid fire hazards;
3. When replacing the fuse, always turn off the power switch to prevent fire and electric shock;
4. Must use a power supply of $220V\pm 22V$, $50HZ\pm 1HZ$ and an effectively grounded socket;
5. Using a damaged or modified power cord may cause fire and electric shock hazards;
6. If the instrument is loose, falling, or damaged, please contact the company in a timely manner;
7. Do not use the instrument in unstable environments such as tilting, vibrating, or impacting conditions;
8. No water or debris is allowed to enter the interior of the instrument. In case of foreign objects entering, please contact the company promptly;
9. When moving the instrument, the power plug must be pulled out first;
10. When moving the instrument, try to avoid vibration;
11. The instrument should be placed on a stable surface, with at least 5cm of space left around it to ensure air circulation and facilitate heat dissipation of the instrument;
12. Do not cover the instrument with anything to prevent blockage of the air vents;
13. Avoid using the instrument in the following environments: direct sunlight; high humidity environments; near water; vibrating or tilting places; strong magnetic field environments; places where electromagnetic waves or impulse voltages occur; places where chemicals are stored or corrosive gases exist;

Product Packaging List

Name	Image Quantity
Main Unit	1
Insulated Handle	1
Mushroom-Shaped Glass Electrode Tube	1
Curved Glass Electrode Tube	1
Tongue-Shaped Glass Electrode Tube	1
Straight Glass Electrode Tube	1
Power Cord	1

Product Specifications

- Input Voltage: AC 220V-240V
- Product Frequency: 50/60HZ
- Product Power: 15W
- Packaging Dimensions: 22x22x20CM
- Gross Weight: 1.5KG
- Net Weight: 1.25KG

14. This instrument shall not be placed or used near radios, televisions, copiers, fax machines, etc.;
15. Do not use it together with other instruments (such as microwaves) to avoid mutual interference between instruments and cause misoperation;
If an abnormal situation occurs to the instrument or the user during operation,
16. the operator shall immediately move the operation handle away from the user, press the stop switch, and stop using the instrument;
17. The instrument shall be correctly used by skilled operators. Personnel other than operators are not allowed to use the instrument;
18. After the operation, place the control handle back on the control handle holder;
19. After using the operation handle, clean the probe thoroughly for next use.

Precautions for Troubleshooting, Storage, and Inspection

1. Do not use the instrument if it malfunctions. In case of smoke, burning smell, or inability to operate, continued use may cause fire or electric shock. Immediately press the stop button, turn off the power, unplug the power plug, and contact the company or distributor immediately;
2. Personnel other than professional technicians are strictly prohibited from repairing or modifying the instrument. The interior of the instrument must never be opened;
3. The instrument and its components must be inspected regularly;
4. Do not use cleaning tools that may damage the instrument's protective coating, such as brushes, brooms, etc.;
5. If the instrument is not used for more than 2 weeks, it must be carefully inspected before reuse.

Contraindicated Groups (Do Not Use If You Belong to the Following Groups)

- Individuals with implanted cardiac pacemakers, defibrillators, or metal implants (such as steel plates, bone nails) in the body;
- Pregnant women, lactating women, and women during menstruation;
- Patients with epilepsy, hypertension, severe heart disease, diabetes, tumors or cancer, or thyroid diseases;
- Individuals with open wounds, skin damage, severe inflammation, eczema, dermatitis on the skin, or those with facial telangiectasia (spider veins) or rosacea;
- Those who have received botulinum toxin injections, filler injections, laser treatments, chemical peels, or plastic surgery recently (usually within 6 months).

Post-Use Operation

- Shutdown Sequence: First adjust the intensity knob back to the lowest gear or "0" position, then turn off the power;
- Remove the Electrode: After turning off and unplugging the power, carefully remove the glass electrode tube. Do not pull it hard;
- Cleaning and Maintenance: Clean the instrument handle and electrode tube with a soft damp cloth, and store them in a cool and dry place after drying.



Instrument Introduction

1. Connect the device to a 220V power supply. The device will emit a "beep" sound, indicating that it is powered on and enters standby mode. The digital tube displays the set time of 30 minutes, the default energy is 0 gear, and the energy bar is fully off;
2. Press the (+) and (-) buttons on both sides of the digital tube time window to control the working time. The setting range is 1-60 minutes, with a step size of 1 minute per adjustment;
3. Press the (+) or (-) buttons on both sides of the energy display bar to adjust the energy up or down. There are 0-10 gears adjustable. Gear 0 means output is off, and gear 10 is the highest intensity;
4. Press the (power) button to start the high-frequency function and begin the countdown. When the time is up, the device will emit a "beep-beep-beep~" prompt sound, the function will turn off, the time will reset to 30 minutes, and the energy will reset to 0 gear.